

TONIC

FLOOR DRILLING TEMPLATE

1. Define longer axis of the bathtub
2. Mark drilling line on the floor to be parallel with longer axis of the bathtub, and 165 mm away (overflow side)
3. Drill two holes $\varnothing 12$ mm, 70 mm deep, as marked on the drilling line
4. Remove dust from holes and Insert PVC plugs to be aligned with the floor surface
5. Insert bolts 8x60 mm in plugs and screw them using Torx wrench Tx 25 until plastic cap of the bolt reaches the floor level

