

FLOOR DRILLING TEMPLATE

- 1. Define position of the bathtub.
- 2. On the floor mark axis of the bathtub perpendicular to the bathtub's ledge.
- 3. Using spirit-level mark extent of the bathtub on the axis line.
- 4. Move the bathtub away and mark another sign on the axis line 450 mm away from the bathtub's extent mark towards the bathtub's center.
- 5. Through that sign draw drilling line perpendicular to the bathtub's axis.
- 6. Mark drilling positions on the drilling line according to the drawing.
- 7. Drill two holes ø12 mm, 70 mm deep.
- 8. Remove dust from holes and Insert PVC plugs to be aligned with the floor surface.

BORE A HOLE ø12 mm

FLOOR LEVEL

9. Insert bolts 8x60 mm in plugs and screw them using Torx wrench Tx 25 until plastic cap of the bolt reaches the floor level.

