OVAL

FLOOR DRILLING TEMPLATE

- 1. Define position of the bathtub and mark longer axis.
- 2. Mark direction line on the floor to be parallel to the longer axis of the bathtub and 130 mm away.
- 3. Mark drilling positions on the direction line according to the drawing.
- 4. Drill two holes ø12 mm, 70 mm deep.
- 5. Remove dust from holes and Insert PVC plugs to be aligned with the floor surface.
- 6. Insert bolts 8x60 mm in plugs and screw them using Torx wrench Tx 25 until plastic cap of the bolt reaches the floor level.

