

VENICE

FLOOR DRILLING TEMPLATE

1. Define position of the bathtub and mark longer axis on the floor.
2. Mark drilling positions on the axis line according to the drawing.
3. Drill two holes $\varnothing 12$ mm, 70 mm deep.
4. Remove dust from holes and Insert PVC plugs to be aligned with the floor surface.
5. Insert bolts 8x60 mm in plugs and screw them using Torx wrench Tx 25 until plastic cap of the bolt reaches the floor level.

